
Onan

Parts Manual

CCKB Engines



927-0404 (Spec G-J) 5-78 (Spec G-J) 4-81 Printed in U.S.A.

SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of the equipment and replacement of parts. Please read and observe.

ADANGER

This symbol warns of immediate hazards which will result in severe personal injury or death.

AWARNING
This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.

ACAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO., and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameptate information in the spaces below:

MODEL AND SPEC NO.

SERIAL NO.

PRODUCT SAFETY PRECAUTIONS

AWARNING

Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.

AWARNING

Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!

AWARNING

Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives, or using solvents take all necessary precautions not to ingest, breathe the fumes, or contact the liquids. Use adequate ventilation and wear protective gloves, masks and clothing!

INDEX

GROUP TITLES	LOCATION	
DATA TABLE	A4	
INTRODUCTION	A4	
STANDARD ENGINE GROUPS	A4	
Block, Cylinder	A6,7	
Box, Ignition Breaker	B5	
Camshaft	A10	
Carburetor Parts - Gasoline - Begin Spec H	B2	
Carburetor Parts - Gasoline - Spec G Only	B3	
Crankshaft and Flywheel	A5	
Fuel System	A12,13	
Gearcase	Á11	
Governor	B10	
Housing, Air	B10	
Ignition System (Battery) - Key 2	B6,7	
Ignition System (Magneto) - Key 1	B4	
Piston and Rod	A10	
Pump Parts, Fuel	B1	
Service Kits and Miscellaneous	B11	
Spark Advance Mechanism - Key 1	A14	
Starter - Spec G and H	B8	
Starter - Begin Spec J	B9	Optional Group
OPTIONAL EQUIPMENT SECTION		Number
Alternator (Automotive Type) Left Side Mounting	C2	1
Alternator (Automotive Type) Right Side Mounting	C2	2
Alternator (Automotive Type) Top Mounting	C3	3
Alternator, Flywheel (15 Ampere Phelon) - Key 2	C4	5
Alternator, Flywheel (20 Ampere Syncro) - Key 2	C4	6
Alternator, Flywheel (WICO) - Key 2	C3	4
Box, Ignition Breaker - (High Profile)	C14	19
Carburetor (Gasoline, Electric Choke) - Spec G Only	D4	24
Carburetor (Gas-Gasoline, Manual Choke) - Spec G Only	D5	25
Carburetor (Gas-Gasoline, Electric Choke) - Spec G Only	D6	26
Carburetor (Gas) - Spec G Only	D7	27
Carburetor (Gasoline, Electric Choke) - Begin Spec H	D8	28
Carburetor (Gas-Gasoline, Manual Choke) - Begin Spec H	D9	29
Carburetor (Gas-Gasoline, Electric Choke) - Begin Spec H	D10	30
Carburetor (Gas) - Begin Spec H	D11	31
Choke, Thermo Magnetic		
Control (Engine)	C9	12
Control (Engine)	C9	13
Filter, Fuel	D3	22
Filter, Oil	D3	23
Fuel System (Gaseous Fuel)	C5	8
Gear Reduction (3:31)	C11	15
Gear Reduction (4:1)	C7 C8	10
Generator (Automotive Type)	C5	11 7
Housing, Air - Vacu-Fio Cooling (And Flywheel)	C10	=
Miscellaneous Parts		14
Starter Readi Pull - Key 1	D12,13 C6	9
Starter (Solenoid Shift) - Key 2	D2	9 21
Tank, Fuel (Day) One Quart	C12	21 16
Tank, Fuel (Day) Two Quart	C12	17
Tank, Fuel (Side Mounted)	C13	18
, , , , , , , , , , , , , , , , , , , ,	- - 10	10

INTRODUCTION

This catalog applies to the industrial CCKB Engines listed below and factory installed options. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the MODEL and SPEC NO. from the engine nameplate, select the Parts Key No. (1,2,etc., in the last column) that applies to your Engine Model and Spec No. This Parts Key No. represents parts that differ between models. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left engine sides are determined by facing the blower end (front) of the engine.

ENGINE DATA TABLE

MODEL AND SPEC NO.	PARTS KEY NO.
CCKB-S*	1
£CCKB-MS/*	2


^{* -} The Specification Letter Advances (A to B,B to C, etc.) with manufacturing changes.

STANDARD ENGINE PARTS SECTION

This section contains the engine parts used on standard engines listed in the Engine Data table.


^{£ -} New model designations shown, begin during 1969. Previous designations used a V in the model to designate Vacu-Flo cooling.

CRANKSHAFT AND FLYWHEEL



REF. NO.	PART .NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USE	
1	104-1316	1	Crankshaft (Includes Parts	10	WASHER, FL.	A'I -WHE	EL MOUNTING
			Marked *)		526-0017	1	Key 1 (15/32" ID x 1-1/4" OD x
2	515-0001		*Key Crankshaft Gear Mounting				1/4" Thk)
3	515-0227	1	Key, Wheel Mounting (Kit)		526-0128	1	Key 2 (15/32" ID x 1-1/2" OD x
			(Includes Parts Marked †)				1/4" Thk)
	515-0002	1	†Key (#9-3/4" x 3/16")	11	850-0055	1	Washer, Lock - Spring Flywheel
	515-0098	1	*†Key (#61-5/8" x 3/16")				Mounting
4	104-0032	1	Gear, Crankshaft	12	SCREW, WHE	EEL MOL	INTING
5	104-0043	1	Washer, Crankshaft Gear		104-0170	1	Key 1
			Retainer		104-0369	1	Key 2 - Spec G and H
6	518-0014	1	Lock, Crankshaft Gear Washer		104-0170	1	Key 2 - Begin Spec J
7	KEY, CRANK	SHAFT S	STUB (Order By Length)	13	192-0083	1	Roper, Manual Starting
	515-0198	1	2-1/2" lg	14	192-0296	1	Backplate - Rope Sheave
	515-0202	1	2-3/8" ig				(Optional - Key 2)
8	FLYWHEEL-	KEY 1 (In	cludes Magnets: 2-160-0748, 2-160-0751)	15	134-0673	1	Ring Gear, Flywheel - Key 2
	160-0761 .	1	Spec G and H	16	192-0308	1	Sheave Rope (Optional -
	160-1072	1	Begin Spec J				Key 1, 2)
9	FLYWHEEL ((Includes	Ring Gear)				
	134-1684	1	Key 2 - Spec G and H				l316 Crankshaft Kit.
	134-2728	1	Key 2 - Begin Spec J	† -	Parts Included	d in 515-0	227 Wheel Mounting Kit.


CYLINDER BLOCK



CYLINDER BLOCK

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	110-0915	1					
•	110-0915	1	Block Assembly, Cylinder (Includes Parts Marked *)	24 25	110-0880	2	Valve, Exhaust
2	123-0954	1	Cap and Valve, Breather ~	25	INSERT, EXH		
2	120-0304	,	Begin Spec H		110-0872	2	Standard
2A	123-0787	1	Cap, Breather Tube -		110-0872-02	2	.002" Oversize
27	120-0707	,	Spec G Only		110-0872-05	2	.005" Oversize
3	TUBE, BREA	THED	Spec & Only		110-0872-10	2	.010" Oversize
J	123-0868	1	Spec G Only	00	110-0872-25	2 4	.025" Oversize
	123-0953	1	Begin Spec H	26	110-0902	•	Guide, Valve
4	123-0865	1	•	27	110-0539	4	Spring, Valve
5	505-0057	1	Baffle, Breather Tube	28	110-0893	2	Washer, Spring Retainer -
J	303-0037	'	Plug (1/8"), Pipe - Oil Line Plug		110.0000	_	Intake Valve
6	110-0666	2	· ·	29	110-0639	8	Lock, Valve and Spring
7	110-0667	2	Cover, Valve Compartment Gasket, Valve Cover		T40000		Retainer
8	517-0048	1		30	TAPPET, VAL		.
0	317-0046	1	*Plug, Camshaft Expansion		115-0006	4	Standard
9	800-0512	5	- Key 2		115-0006-05	4	.005" Oversize
9	000-0512	5	*Screw, Cap - Hex Head	31	110-0904	2	Rotocap, Exhaust Valve
			Bearing Plate Mounting -	32	110-1283	1	*Cover, Timing Control-
			Replaces Stud and Nut Used				Key 1
10	500 0000		On Early Models (Special)	33	123-0951	1	Clamp, Breather Tube Cap -
10	502-0020	1	Elbow, Street - Oil Line			_	Begin Spec H
11 12	110-0892	2	Gasket, Cylinder Head	34	123-0958	2	Screen, Breather Tube -
12	HEAD, CYLII		1.611. 1.694				Begin Spec H
	110-0883	1	Left Hand (#1)	35	509-0117	1	"O" Ring, Breather Tube
10	110-0884	1	Right Hand (#2)				Cap - Begin Spec H
13			AFT - FRONT AND REAR	36			AD-CYLINDER
	101-0450	2	Standard - Begin Spec J		HEAD MOUN		_
	101-0450-02	2	.002" Undersize		110-0879	8	Special
	101-0450-10	2	.010" Undersize		114-0022	10	Special
	101-0450-20	2	.020" Undersize	37	526-0122	18	Washer, Flat - Cylinder
4.4	101-0450-30	2	.030" Undersize				Head Mounting (11/32" ID
14	104-0575	2	Washer, Crankshaft Bearing				x 23/32" OD x 10 Ga. Thk)
15	101 0115	4	Thrust	38	800-0012	2	Screw, Cap - Hex Head
16	101-0115	1	*Gasket Kit, Bearing Plate				Valve Cover Mounting
10	101-0316	1	*Plate, Rear Bearing	••			(1/4-20 x 2-1/4" lg)
17	101 0405	•	(Excludes Bearing)	39	526-0063	2	Washer, Flat - Valve Cover
17	101-0405	2	*Bearing, Camshaft Front and				Mounting (17/64" ID x 7/16"
18	E00 0041		Rear (Precision)			_	OD x 1/32" Thk)
_	509-0041	1	Seal, Bearing Plate	40	850-0045	5	Washer, Lock - Spring - Bearing
19	516-0072	2	*Pin, Main Bearing Stop				Plate Mounting (5/16")
20	110-0445	5	Nut, Bearing Plate Stud	41	809-0035	1	Screw, Tapping, Pan Head
			(Special) Used On Early		alabas hasadamadda a da ada la la sa sa la la l	- 1-1	Breather Clamp (#8 x 3/4")
n.	100 0015		Models		516-0141		Pin, Gear Cover Alignment
21	123-0315	1	Valve, Breather Tube -		110-3136		'Gasket, Intake Valve Guide
20	100 0000		Spec G Only	44	104-0776	1	Shim, Crankshaft Thrust Bearing
22 23	120-0386	1	*Tube, Crankcase Oil				
23	110-0881	2	Valve, Intake	• -	Parts Included	in 110-0	915 Cylinder Block Assembly.


OIL SYSTEM




927-0404 (APRIL 1981)

OIL SYSTEM

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	BASE, OIL			10	526-0066	1	Washer, Flat - Oil By-Pass
	102-0468	1	Key 1				(25/64"ID x9/16"OD x 1/6"Thk)
	102-0339	1	Key 2 - Spec G and H	11	120-0140	1	Spring, Oil By Pass Valve
	102-0861	1	Key 2 - Begin Spec J	12	120-0398	1	Valve, Oil By Pass
2	TUBE, OIL F	ILL		13	120-0161	1	Gasket Kit, Oil Pump
	123-0508	1	Spec G and H	14	PLUG, OIL	DRAIN	•
	123-0674	1	Begin Spec J		505-0110	1	Some Early Models (3/8")
3	CAP AND IN	DICATOR	R, OIL FILL		505-0056	1	Late Models (1/2")
	123-0506	1	Key 1 - Spec G and H	15	102-0455	4	Screw, Cap - Hex Head Oil Base
	123-0762	1	Key 1 - Begin Spec J				Mounting (Special)
	123-0527	1	Key 2 - Spec G and H	16	850-0050	4	Washer, Lock - Spring Oil Base
	123-0694	1	Key 2 - Begin Spec J				Mounting (3/8")
4	123-0191	1	Gasket, Oil Fill Cap	17	800-0004	2	Screw, Cap - Hex Head - Oil Fill
5	102-0158	1	Gasket, Oil Base				Tube Mounting(1/4-20 x 5/8" lg)
6	CUP, OIL PU	MP INTAI	KE	18	850-0040	2	Washer, Lock - Spring Oil Fill
	120-0413	1	Key 1				Tube Mounting (1/4")
	120-0648	1	Key 2	19	800-0007	2	Screw, Lock - Spring - Oil Pump
7	141-0078	1	Gasket, Oil Fill Tube				Mounting (1/4-20 x 1" lg)
			Mounting	20	850-0040	2	Washer, Lock - Spring - Oil
8	120-0491	1	Pump, Oil (Internal Parts Not Sold Separately)				Pump Mounting (1/4")
9	801-0048	1	Screw, Cap - Hex Head Oil By- Pass (3/8-24 x 3/4" lg)				





				Centile 1				
REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REI NO		PART NO.	QTY. USED	PART DESCRIPTION
1	150-0078	1	Ring, Camshaft Center Pin	10)	150-0075	1	*Pin. Center - Camshaft
2	150-1695	1	Cup, Governor (Kit) (Include Parts Marked **)	es 1 ⁻	1	105-0058	1	Plunger, Camshaft Thrust (Manually Controlled Engine)
3	510-0015	5	Ball - Governor	12	2	105-0059	1	Spring, Camshaft Plunger
4	150-1257	1	†Spacer, Governor Fly Ball, B	egin				(Manually Controlled Engine)
			Serial #370369 During Spe	cH 13	3	150-1519	1	**Hub, Governor Cup
5	150-0077	1	†Plate, Governor Fly Ball, Beg	in 14	1	150-1520	1	"Cup and Bushing, Governor Cup
			Serial #370369 During Spe	c H 15	5	105-0030	1	†Gear, Camshaft
6	105-0332	1	Gear, Camshaft (Includes Pa	rts				
			Marked †)	•	_	Parts Includ	ed in Can	nshaft Assembly.
7	105-0541	1	Washer, Camshaft Gear Thru	ıst ••				-1695 Governor Cup Kit.
8	515-0001	1	Key, Camshaft Gear Mountin	ıg +				-0332 Camshaft Gear Assembly.
9	CAMSHAFT	(Includes	Center Pin)			. 4.10	00 111 100	oos camenan acai rioscinory.
			KEY 1					
	105-0234	1	Spec G and H	STON AND	_	00		
	105-0295	1	Begin Spec J	STON AND	Н	OD		
	105-0238	1	Key 2					
			6					



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	PISTON AND	PIN (Inc	cludes Retaining Rings) Piston Has Slotted	5	RING SET, PI	STON	
	Oil Ring Gr	oves (To	p Grove 5/32" From Top of Piston)		113-0153	2	Standard
	(Includes Page 1)	arts Mari	ked *)		113-0153-05	2	.005" Oversize
	112-0179	2	Standard		113-0153-10	2	.010" Oversize
	112-0179-05	2	.005" Oversize		113-0153-20	2	.020" Oversize
	112-0179-10	2	.010" Oversize		113-0153-30	2	.030" Oversize
	112-0179-20	2	.020" Oversize		113-0153-40	2	.040" Oversize
	112-0179-30	2	.030" Oversize	6	805-0010	4	Bolt, Place - Connecting Rod
	112-0179-40	2	.040" Oversize	7	114-0036	2	Bushing, Piston Pin -
2	112-0069	2	Pin, Piston				Connecting Rod
3	112-0003	4	*Ring, Piston Pin Retainer	8	BEARING, CO	DNNECT	ING ROD
4	114-0203	2	Rod Assembly, Connecting		114-0188	4	Standard
			(Forged) - Includes Bushing		114-0188-02	4	.002" Undersize
			and Place Bolts		114-0188-10	4	.010" Undersize
					114-0188-20	4	.020" Undersize
					114-0188-30	4	.030" Undersize

GEARCASE






C-1048

REF. NO.	PART NO.	QTY.	PART	REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1	509-0008	1	†*Seal, Oil - Governor Shaft	10	COVER ASS	EMBLY,	GEAR
2	510-0013	1	†*Bearing, Governor Shaft		103-0655	1	Spec G and H
			Upper (Spec J Use 2)				(Includes Parts Marked *)
3	ARM & SHAF	FT ASSE	MBLY, GOVERNOR		103-0480	1	Begin Spec J
	150-1422	1	†Begin Spec J				(Includes Parts Marked †)
	150-1315	1	*Spec G and H	11	103-0011	1	Gasket, Gear Cover
4	YOKE, GOVE	ERNOR S	SHAFT	12	815-0181	1	Screw, Cup - Hex Head with
	150-1187	1	†*Begin Spec J				External Lock Washer
	150-0620	1	Spec G and H				(#10-32 x 1/2" lg)
5	518-0129	1	Ring, Yoke Retainer -	13	SCREW, CA	P-HEX HI	EAD
			Spec G and H		800-0034	1	5/16-18 x 2-1/4" lg
6	516-0130	1	†*Pin, Governor Cup Stop		800-0032	4	5/16-18 x 1-3/4" lg
7	BEARING, G	OVERNO	DR SHAFT — LOWER	14	815-0046	2	†*Screw, Machine - Pan Head
	510-0013	1	*Begin Spec J				Yoke Mounting
	510-0008	1	*Spec G and H				(#8-32 x 3/8" lg)
8	510-0014	1	†*Ball, Bearing - Governor				Begin Spec J
			Shaft	15	850-0045	5	Washer, Lock-Spring-Gear Cover
9	EXTENSION	, GOVER	NOR ARM - STANDARD GOVERNORS				Mounting (5/16")
	ONLY			16	509-0040	1	†*Seal, Gear Cover
	150-1000	1	Spec G Only	17	516-0141	2	Pin, Gear Cover Alignment
	150-1073	1	Begin Spec H				(5/16 x 1-1/8" tg)
				18	167-0188	1	Clip, Oil Fill Mtg Tube

^{* -} Parts Included in 103-0655 Gear Cover Assembly. † - Parts Included in 103-0480 Gear Cover Assembly.

FUEL SYSTEM






F-0-1133

FUEL SYSTEM

(Includes Parts Marked †) (See Separate Group for Components) 140-0760 1 Spectified 140-1792 1 Key 1 140-1304 1 Begin 149-1784 1 Key 2 17 PAN, AIR CLEANER 2 149-1024 1 Rod, Fuel Pump Primer - 140-0828 1 Spectified 140-0595 1 Begin 3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 502-0065 1 Spec G and H	PART
(Includes Parts Marked †) (See Separate Group for Components) 140-0760 1 Special 140-1792 1 Key 1 140-1304 1 Begin 149-1784 1 Key 2 17 PAN, AIR CLEANER 140-0828 1 Special 140-0828 1 Special 140-0828 1 Special 140-0595 1 Begin 3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 502-0065 1 Spec G and H	DESCRIPTION
(See Separate Group for Components) 140-0760 1 Spector 149-1792 1 Key 1 140-1304 1 Begin 149-1784 1 Key 2 17 PAN, AIR CLEANER 2 149-1024 1 Rod, Fuel Pump Primer - 140-0828 1 Spector Key 1 140-0595 1 Begin 3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 19 503-0301 2 Clamp 502-0065 1 Spec G and H Carl	et, Fuel Pump Mounting
149-1792 1 Key 1 140-1304 1 Begin 149-1784 1 Key 2 17 PAN, AIR CLEANER 2 149-1024 1 Rod, Fuel Pump Primer - 140-0828 1 Spec Key 1 140-0595 1 Begin 3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 19 503-0301 2 Clamp 502-0065 1 Spec G and H Carl	0.0-4-
149-1784 1 Key 2 17 PAN, AIR CLEANER 2 149-1024 1 Rod, Fuel Pump Primer - 140-0828 1 Spec of the spec of th	
2 149-1024 1 Rod, Fuel Pump Primer - 140-0828 1 Spec Key 1 140-0595 1 Begin Social Spec G and H	Spec H
Key 1 140-0595 1 Begin 3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 19 503-0301 2 Clamp 502-0065 1 Spec G and H Carl	G Only
3 ELBOW, CARBURETOR INLET 18 140-0636 1 Eleme 502-0313 1 Begin Spec J 19 503-0301 2 Clamp 502-0065 1 Spec G and H Carl	
502-0313 1 Begin Spec J 19 503-0301 2 Clamp 502-0065 1 Spec G and H Carl	nt, Air Cleaner
502-0065 1 Spec G and H Carl	, Fuel Pump to
	buretor Hose
4 LINE, FUEL-PUMP TO CARBURETOR 20 140-0594 1 Cover	. Air Cleaner
	t, Air Cleaner
149-1097 1 Spec H Only - Metal 22 GASKET, ADAPTER TO CARI	
are an armine the second secon	G Only
	Spec H
	Spec J - Key 1
	Air Cleaner
	/4-20) Wing
	er (1/4")
20 120 100	Adapter to Breather Hose
	er. (Copper), Pump
	inting - Used on Early
	/16-24) - Carburetor
20 000 0001 2 1101/0	inting
	er, Shakeproof -
	ouretor Mounting (5/16")
	(10-32 x 1/2"), Round
	d - Air Inlet to Carburetor
	er (#10) - Flat Air Inlet
	inting
8 155-0916 2 Muffler, Exhaust 32 WASHER, LOCK	5
9 505-0086 2 Nipple (1 x 2-1/2"), Exhaust 850-0030 2 Air Inli	et Mounting (#10)
***	Manifold Mounting (3/8")
11 520-0526 2 Stud, Carburetor Mounting 34 800-0057 2 Screw	(3/8-16 x 2-3/ 4") - intake
· · · · · · · · · · · · · · · · · · ·	ifold Mounting
	, Counterbore - Fuel
	Not Shown)
* - Parts Included in 141-0774/14	i-0878 Carburetor Kit.
† - Parts Included in 149-1784/149	-1792 Fuel Pump Kit.


^{927-0404 (}APRIL 1981)

SPARK ADVANCE MECHANISM - KEY 1




REF.	PART	QTY.	PART	REF.	. PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.		USED	
1	160-0791	1	Cam, Timing Control	5	SPRING, TIM	ING CON	TROL
2	516-0144	4	Pin, Roll (7/16")		160-0727	1	Spec G and H
3	WEIGHT AS	SEMBLY (Includes Pins) -		160-1051	1	Begin Spec J
	TIMING C	ONTROL	·	6	160-0726	1	Retainer, Timing Control
	160-0789	2	Magneto Ignition (Spec G and H)	-			(Spec G and H)
	160-1049	2	Begin Spec J	7	RING. RETAIL	NING - TIN	MING CONTROL
	160-0790	2	Battery Ignition (Spec G and H)		518-0185	2	Spec G and H
	160-1198	2	Begin Spec J		518-0129	2	Begin Spec J
4	PIN. GROON	E-TIMIN	GCONTROL		0.00.00	-	Dog Open C
	516-0146	2	Spec G and H				
	516-0172	2	Begin Spec J				

FUEL PUMP PARTS




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	PUMP, FUEI	L (Include	s Mounting Gasket)	10	516-0113	1	Pin, Rocker Arm
	149-1792	1	Key 1	11		1	Body (Not Sold Separately)
	149-1784	1	Key 2	12	149-0710	1	Link and Arm. Rocker (Sold only as a set)
	149-0526	1	Kit, Fuel Pump Repair (Includes Parts Marked *)	14	LEVER, PRIN	MER 1	Key 1
	149-0003		*Gasket, Mounting		149-0551		Key 2
1		1	Body (Not Sold Separately)	15	509-0065	9	Seal, "O" Ring
2	815-0148	4	Screw (#8-32 x 7/8")	15 16	SPRING.PR	MERLEV	
3	815-0147	2	Screw (#8-32 x 7/8")	10	149-1044	1	Key 1
			Phillips - Valve Retainer		149-0404	1	Key 2
4	149-0096	2	Valve and Cage	17	149-0003	1	'Gasket, Pump Mounting
5	149-0095	2	*Gasket, Valve	18	518-0129	1	Ring, Retainer - Primer
6	149-0582	1	*Diaphragm Assembly				Lever
7	149-0672	1	*Spring (Replaces 149-0093)	19	149-0858	1	*Gasket, Diaphragm - Lower
8	149-0539	1	Retainer, Valve Cage				Side
9	149-0675	1	'Spring (Replaces 149-0094)	٠.	Parts Include	ed In 149-	0526 Repair Kit.

CARBURETOR PARTS - GASOLINE - BEGIN SPEC H




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	
			OLINE (Includes	11	141-0701	1	£*Gasket, Bowl to Body
	Mounting G		OEMICE (MINISTERS	12	141-0700	1	Screw, Throttle Stop
	141-0878	1	Manual Choke	13	141-0711	1	Spring, Throttle Stop
	141-0747	1	Kit, Carburetor Repair	14	NEEDLE, A	DJUSTIN	G
		•	(Includes Parts Marked *)		141-0713	1	Gasoline Units
	141-0748	1	Kit, Carburetor Gasket	15	SPRING, ID	LE NEED	LE
		•	(Includes Parts Marked £)	16	141-0077	1	£'Washer, Main Jet Assembly
	141-0281		£'Gasket Carburetor Flange	17	141-0712	1	Jet Assembly, Main (Adjustable)
1	141-0708	1	Bowl, Fuel	18	SHAFT, CH	OKE	
2	141-0741	1	Plate, Choke		141-0742	1	Manual Choke Units
3	141-0698	4	Screw & Washer, Choke and	19	141-0699	1	Washer
			Throttle Plate Mounting	20	141-0697	1	£*Seal, Felt
4	141-0706	1	Plate, Throttle	21	141-0203	1	*Retainer, Felt Seal
5	141-0705	1	*Retainer, Seal	22	141-0709	1	Shaft and Lever, Throttle
6	141-0661	1	£*Seal, Rubber	23	141-0799	1	*Spring, Float
7	141-0830	1	*Valve Seat Assembly, Fuel				
8	141-0811	1	£Washer, Fuel Valve Seat	• .	Parts Includ	ded 141-0	747 Carburetor Repair Kit.
9	141-0703	1	*Shaft, Float				748 Carburetor Gasket Kit.
10	141-0702	1	Float Assembly	~	. 2.151110101		


CARBURETOR - GASOLINE - SPEC G ONLY



REF. NO.	PART NO.	QTY. USED		REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	CARBURET 141-0774	OR GAS	OLINE (Includes Mounting Gasket) Manual Choke	10 11	143-0105 143-0210	1	Float and Lever Bowl
	143-0332 143-0201	1	Kit, Carburetor Repair (Includes Parts Marked **)	12 13	143-0077 141-0703	1 1	*Gasket, Bowl Ring **Pin, Float Lever
			**Kit, Carburetor Gasket (Includes Parts Marked *)	14 15	143-0341 143-0213	1	**Valve, Fuel Inlet Screw, Idle Adjusting
1	141-0281 143-0202	1	*Gasket, Carburetor Flange Valve, Throttle	16	812-0014	4	**Screw (#3-48 x 3/16") - Choke and Throttle Valve
3 4	143-0220 143-0330	1	Valve, Choke - Manual Choke "Needle, Idle Jet and High	17 18	143-0110 143-0214	1 1	Plug, Expansion Spring, Throttle Adjusting
5 6	143-0329 143-0221	1	Speed Adjusting **Nozzle Shaft and Lever, Choke	19 22	143-0112 854-0003	1 4	Screw Spring, Idle Adjusting Screw
7 8	143-0208 143-0015	1	Screw and Gasket, Bowl				**Washer, Lock (IT #3)
9	143-0209	i	*Gasket, Fuel Inlet Valve *Gasket, Bowl Screw				-0201 Carburetor Gasket Kit. -0332 Carburetor Repair Kit.

IGNITION SYSTEM (MAGNETO) - KEY 1






REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY.	PART
NO.			DESCRIPTION	NU.	NO.	USED	DESCRIPTION
1	PLUG, SPAR	łK		5	160-0750	1	*Coll, Magneto Stator
	167-0241	2	Non-Resistor Type	6	160-0749	1	*Pole Shoe, Magneto Stator
	167-0237	2	Resistor Type	7	526-0015	2	Washer, Flat (9/32" ID x
2	508-0095	2	Grommet, Rubber - Spark				9/16" OD x 1/16" THK)
			Plug Cables	8	526-0184	2	Washer, Flat (17/64" ID x
3	CABLE, SPA	RK PLUG					5/8" OD x #10 Gauge)
			Key 1	9	815-0259	2	Screw Cap - Hex Head (1/4-20 x
	167-1404	1	Right Hand - Spec G and H				1-1/4" (g)
	167-1593	1	Right Hand - Begin Spec J	10	313-0018	1	Switch, Stop
	167-1403	1	Left Hand - Spec G and H	11	160-0257	1	Box Assembly, Breaker (See
	167-1594	1	Left Hand - Begin Spec J				Separate Group for Complete
			Key 1				Breakdown)
	167-1073	1	Right Hand - Spec G and H	12	167-0188	4	Clip, Spark Plug Cable
	167-1593	1	Right Hand - Begin Spec J	13	332-0273	1	Clip, Magneto Lead
	167-1330	1	Left Hand - Spec G and H	14	334-0028	1	Lead, (4' pieces of wire)
	167-1593	1	Left Hand - Begin Spec J	15	508-0002	1	Grommet, Magneto Lead
4	160-0752	1	Stator Assembly, Magneto	16	160-0043	1	Gasket, Ignition Breaker Box
			(Includes Parts Marked *)	, •			Mounting

^{* -} Parts Included in 160-0752 Magneto Stator Assembly.


IGNITION BREAKER BOX




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART No.	QTY. USED	PART <u>DE</u> SCRIPTION
	160-0257	1	Box Assembly, Breaker -	7	312-0069	1	*Condenser, Ignition Points
			Complete (Includes Mounting	8	160-0043	1	*Gasket, Breaker Box Mounting
			Gasket, Washer and	10	160-0262	1	*Guide and Plunger, Ignition
			Screws) (Includes Parts Marked *)	11	802-0034	2	*Screw, Cap - Socket Head (1/4-20 x 3/4" lg)
1	160-0930	1	*Cover, Breaker Box	12	850-0040	2	*Washer, Lock - Spring (1/4")
2	160-0150	1	*Gasket, Breaker Box Cover	13	850-0025	2	*Washer, Lock - Spring (#8)
3	160-0075	1	*Cam, Breaker Point Gap Adjusting	14	812-0077	2	*Screw, Machine - Round Head (#8-32 x 3/8" lg)
4	160-0002	1	*Point Set Breaker	15	518-0049	3	*Screw, Machine - Round Head
5	160-0349	1	*Block and Terminal Assembly				W/External Tooth -
6	160-0428	1	*Strap, Point Set to Terminal Block				(#8-32 x 1/4" lg)

^{* -} Parts Included in 160-0257 Breaker Box Assembly.

IGNITION SYSTEM (BATTERY) - KEY 2








927-0404 (APRIL 1981)

IGNITION SYSTEM (BATTERY) - KEY 2

REF. NO.	PART NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	160-0257	1	Box, Breaker - Complete (See Separate Group for Complete	8	166-0402	1	Bracket, Coil Mounting - Spec G and H
			Breakdown of Components)	9	503-0514	1	Clamp, Coil - Spec G and H
2 3			Gasket, Breaker Box Mounting	10	160-0558	2	Nipple, Rubber Coil - Spec G and H
	166-0346	1	Spec G and H	11	304-0060	1	Resistor, Ignition - Spec G and H
4	166-0535 CABLE, SPA	1 ARK PLUG	Begin Spec J	12	304-0610	1	Support, Resistor Terminal - Spec G and H
	167-1404 167-1073	1	Key 1 Spec G and H R/H Key 2 Spec G and H R/H	13	304-0014	2	Washer, Resistor Mounting Spec G and H
	167-1403 167-1330 167-1594	1 1	Key 1 Spec G and H L/H Key 2 Spec G and H L/H Key 1 Begin Spec J L/H	14	813-0112	1	Screw, Machine - Round Head Resistor Mounting Spec G and
	167-1595 167-1593 167-1596	1	Key 2 Begin Spec J (24") Key 1 Begin Spec J R/H	15	526-0179	1	H (#10-32 x 2-1/2" Ig) Washer, Flat - Resistor Mounting (Spec G and H)
5	SPARK PLU	G. IGNITI	Key 2 Begin Spec J (15")	+6 .	854-0010	4	(7/32"ID x 5/8"OD x 1/16"Thk)
·	167-0241	2	Non-Resistor Type	10	034-0010	•	Washer, Lock - Internal
	167-0237	2	Resistor Type				Shakeproof-Resistor Mounting Spec G and H (#10)
	166-0702	1	Kit, Lead Replacement (Includes Parts Marked *)	17	870-0053	1	Nut, Hex - Resistor Mounting Spec G and H (#10-32)
6	336-4414	1	*Lead Assembly, Coil to Breaker Box - Begin Spec J	18 19	166-0554 850-2005	1	*Nut, Hex (Special) *Washer, Lock (MS)
7	308-0002	1	Switch, Ignition On/Off	20	166-0604	2	Nut, Ignition Coil

^{* -} Parts Included in 166-0702 Lead Replacement Kit.


STARTER - SPEC G AND H



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. LISED	PART DESCRIPTION
1	191-0511	1	Starter Motor - (Includes Parts	9	191-0517	1	'Armature
			Marked ')	10	191-1017	1	*Coil Assembly Package, Field
2	191-0508	1	Flange, Starter Motor Mounting	11	191-0513	1	*Brush Set, Service
3	308-0028	· · · · · · · · · · · · · · · · · · ·	Switch, Start	12	191-1018	1	*Head Assembly, Commutator
4	332-0570	1	Jumper, Starter to Switch				End Band, Cover (Not Sold
5	SCREW, CA	P-HEX HE	AD-STARTER MOTOR MOUNTING				Separately)
	800-0049	1	3/8-16 x 7/8" Ig	13	191-1019	1	*Bearing Assembly, Intermediate
	800-0050	1	3/8-16 x 1" lg	14	191-0271	1	*Drive Assembly, Bendix
6	850-0050	2	Washer, Lock - Spring Starter	15	191-0735	1	*Bearing, Drive End
			Motor Mounting (3/8")	16	191-1020	1	*Spring, Brush (Set of 4)
7	102-0455	3	Screw, Cap - Hex Head - Starter Motor Flange Mounting	17	191-1021	1	*Washer, Armature Thrust (pkg.) Use as required
8	850-0050	3	Washer, Lock - Spring - Starter Motor Flange Mounting (3/8")	18	191-1022	1	'Stud. Terminal (pkg)

^{* -} Parts Included in 191-0511 Starter Motor

STARTER - BEGIN SPEC J




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	191-1052	1	Starter (Includes Parts Marked *)	10	191-1005	2	*Brush, Starter (Positive)
1	191-1011	1	*Screw & Washer Set	11	191-0997	1	*Insulating, Washer Set
2	191-0987	1	*Solenoid Assembly	12	191-1088	1	*Armature, Starter
3	191-0988	2	*Bolt - Hex Washer Head	13	191-0984	1	*Plate & Spring Set
4	191-1009	1	*Bracket, Rear - Starter (Includes	14	191-0983		*Lever, Clutch
			Rear Sleeve Bearing)	15	191-1087	1	*Clutch & Pinion Gear
5	191-1010	1	*Bearing, Sleeve (Rear)	16	191-0991	1	*Stop Retaining Set - Pinion Gear
6	191-1006	1	*#Holder, Brush (Includes Negative Brush and Brush Springs)	17	191-1086	1	*Bracket, Front - Starter (Includes Front Sleeve Bearing)
			(Includes Parts Marked Δ)	18	191-0971	1	*Bearing, Sleeve (Front)
7	191-1008	1 #/	∆*Brush, Starter (Negative)	19	191-1076	1	Seal, Air Begin Spec J
8	191-1007	3 #	∆*Spring, Helical. Compression (Brush)	20	850-0050	2	Washer, Lock - Spring - Starter Mounting
9	191-1089	1	Yoke Assembly, (Includes Frame, Pole Shoes, Field Coil and Replaceable Positive Brushes)	21	800-0050	2	Screw, Cap - Hex Head - Starter Motor Mounting (3/8-16 x 1")

- # Early Brush Holder equipped with Two (2) Negative Brushes and Four (4) Brush Springs-Completely Interchangeable with Current Brush Holder.
- * Parts Included in 191-1052 Starter Motor
- $\Delta\,$ Parts included in 191-1006 Brush Holder Assembly.

GOVERNOR

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION		
1	150-0098	1	Spring, Governor	8/12	"YX
2	150-1023	1	Stud, Speed Adjustment	9 5	-///
3	150-1262	1	Bracket, Speed Stud		
4	870-0131	1	Nut, Speed Adjusting (#10-32)	7~	S
5	JOINT, BALL		, , , , , , , , , , , , , , , , , , , ,		(
	150-0974	2	Spec G Only	1	9
	150-0939	2	Begin Spec H through Serial	6 🗸	1
			#540766 During Spec H-Plastic		
	150-0639	2	Begin Serial #540767 During Spec H - Metal	7-1	
6	LINK, THROT	TLE			
	520-0187	1	Spec G and Begin Serial	. L1	
			#540767 During Spec H	5 // //	
	520-0623	1	Begin Spec H through Serial	· [L]/	
			#540766 During Spec H	L.Y	
7	870-0053	2	Palnut, Locking		
8	870-0131	2	Nut, Keps - Locking Ball Joint (#10-32)	i i	
9	526-0196	2	Washer, Flat - Ball Joint	9 → ⊙	
•	0.00	-	(7/32"ID x 7/16"OD x 1/8"Thk)	O - 65%	
10	821-0010	1	Screw, Self Lock - Hex Washer Head (1/4-20 x 1/2")		4
					1

AIR HOUSING



SERVICE KITS AND MISCELLANEOUS

NOTE: For other kits, refer to the group for the part in question.


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	98-1100	1	Decal Kit, Set
	160-0836	1	Ignition Tune-up Kit
	168-0103	1	Gasket Kit, Complete Engine
	168-0095	1	Gasket Kit, Carbon Removal
	ENGINE OV	ERHAUL F	CIT .
	522-0225	1	Spec G Only
	522-0239	1	Begin Spec H
	TOUCH-UP	PAINT (Pr	ressurized Can)
	525-0137	1	Metallic Green (13 oz.)
	525-0305	1	Non-Metallic Green (13 oz.)
	525-0454	1	Greige Enamel (13 oz).

OPTIONAL EQUIPMENT SECTION

This section contains parts listing of factory installed options. NOTE: options may not be applicable to all models; for field installations, additional parts are usually required.

OPTION 1 ALTERNATOR (AUTOMOTIVE TYPE - LEFT SIDE MOUNTING)

		=	• -
REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
1	191-1233	1	*Alternator Assembly (Includes Parts Marked †) (35 Ampere, 12 Volt)-Motorola
			#RA-12NON451
	191-1232	1	†Alternator, 35 Amp
2	191-1243		*Regulator, Voltage
3	191-0623	1	†Pulley, Alternator
4	BRACKET,	ALTERNA	TOR MOUNTING
	191-0537	1	Pressure Cooled Engine
	191-0539	1	Vacu-Flo Cooled Engine
5	191-0535	1	Bracket, Alternator Adjusting
6	511-0051	1	Belt, Drive
7	191-0134	1	Pulley, Drive - Vacu-Flo Cooled Engine
8	191-0659	1	Brush and Holder Assembly (Part of 191-0573 Alternator)
9	191-0671	1	Diode Assembly, Isolation (Part of 191-0573 Alternator)
10	191-0662	1	Diode Assembly, Rectifier - Negative (Part of 191-0573
11	191-0661	1	Alternator) Diode Assembly, Rectifier - Positive (Part of 191-0573 Alternator
٠.	For compone	anto not lie	ton about electrons and an addition




^{† -} Parts Included in 191-1233 Alternator Assembly.

511-0076


Belt, Drive

Brush and Holder

(Part of 191-0573 Alternator)



OPTION 2 ALTERNATOR (AUTOMOTIVE TYPE - RIGHT SIDE MOUNTING)




REF. NO.	PART NO.	QTY. USED		REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-1233	1	*Alternator Assembly (Includes Parts Marked †) (35 Ampere,	8	191-0671	1	Diode Assembly, Isolation (Part of 191-0573 Alternator)
			12 Volt)-Motorola #RA-12NON451	9	191-0662	1	Diode Assembly, Rectifier - Negative (Part of 191-0573
	191-1232	1	†Alternator, 35 Amp				Alternator)
2	191-1243	1	†*Regulator, Voltage	10	191-0661	1	Diode Assembly, Rectifier -
3	191-0623	1	†Pulley, Alternator				Positive (Part of 191-0573
4	191-0575	1	Bracket, Alternator and Starter Mounting				Alternator)
5	191-0576	1	Bracket, Alternator Adjusting	٠.	For compon	ents not lis	sted, check alternator nameniate

For components not listed, check alternator nameplate and contact your nearest Motorola dealer.


927-0404 (APRIL 1981)

^{† -} Parts Included in 191-1233 Alternator Assembly.


OPTION 3 ALTERNATOR (AUTOMOTIVE TYPE - TOP MOUNTING)




OPTION 4 FLYWHEEL ALTERNATOR (20 AMP WICO) - KEY 2



OPTION 5 FLYWHEEL ALTERNATOR (15 AMPERE PHELON) - KEY 2 - BEGIN SPEC J




	√ 15		
REF. NO.	PART No.	QTY. USED	PART DESCRIPTION
1	813-0143	3	Screw, Machine - Round Head Cross Recessed (#10-32 x 1-3/8")
2	850-0030	3	Washer, Lock - Spring (#10)
3	191-1256	1	Stator Assembly (Includes Par Marked *)
4	821-0018	2	Screw, Cap-Hex Head - Self Locking (1/4-20 x 5/8")
5	191-0886	1	Regulator, Voltage
6	821-0012	2	Screw, Cap - Hex Head - Self Locking (1/4-20 x 1-1/8")



			CS-10
7	191-1107	1	Bracket, Regulator Mounting
8	134-2100	2	Spacer, Regulator Mounting
9	134-2621	1	Flywheel (Includes Ring Gear)
10	134-0673	1	Gear, Ring - Flywheel
11	323-0853	1	*Body, Connector
12	332-2073	3	*Terminal
13	167-0188	2	Clip, Stator Leads
14	191-1254	1	*Stator Only
15	323-1075	1	*Body, Connector


^{* -} Parts Included in 191-1256 Stator Assembly.

OPTION 6 FLYWHEEL ALTERNATOR (20 AMPERE SYNCRO) - KEY 2 - BEGIN SPEC J



REF.	PART	OTV	1		\$			16
NO.	NO.	QTY. USED	PART DESCRIPTION			720000		CS-1072
1	134-2642	1	Flywheel (Includes Ring Gear)	2	10	323-0879		Can Connector (2 Male
2	134-0673	1	Gear, Ring - Flywheel	-	10	323-0019	'	Cap, Connector (2 Male Contacts)
3	821-0010	2	Screw, Cap - Hex Head Locking (1/4-20 x 1/2")		11	323-0880	1	Plug, Connector (2 Female Contacts)
4	191-1107	1	Bracket, Regulator and Rectifier		12	191-0937	1	Stator, Alternator
_			Mounting		13	850-0030	3	Washer, Lock - Spring (#10)
5	815-0181	4	Screw, Cap - Hex Head W/ET Lockwasher (#10-32 x 5/16")		14	813-0108	3	Screw, Machine - Round Head Cross Recessed
6	191-0938	1	Rectifier, Current					(#10-32 x 1-1/4")
7	191-0939	1	Regulator, Voltage		15	323-0488	5	Contact, Connecting - Female
8	323-0882	1	Plug, Connector (3 Female		16	323-0496	5	
			Contacts)		17	167-0188	2	Contact, Connecting - Male
9	323-0881	1	Cap, Connector (3 Male Contacts)	C4	,,	107-0188	2	Clip, Stator Leads 927-0404 (APRIL 1981)

OPTION 7 GENERATOR(AUTOMOTIVE TYPE)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-0277	1 -	Generator
2	191-0229	1	Pulley, Generator
3	511-0051	1	Belt, Generator Drive
4	BRACKET.	GENERATO	OR MOUNTING
	191-0279	1	Pressure Cooled
	191-0304	1	Vacu-flo Cooled
5	191-0280	1	Bracket, Generator Adjustin
6	191-0134	1	Pulley, Generator Drive - Vacu-flo Cooled
7	191-0305	1	Brace, Generator Mounting Bracket - Vacu flo Cooled


† - For components, check nameplate and contact your nearest Delco Remy Dealer.

OPTION 8 OIL FILTER

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	122-0321	1	Gasket
2	526-0065	2	Washer, Flat - Copper (21/64" ID x 9/16" OD x 1/16" Thk)
3	800-0028	2	Screw, Cap - Hex Head (5/16-18 x 1")
4	122-0320	1	Adapter, Filter
5	122-0323	1	Filter, Spin-On
6	122-0347	1	Seal, Air
7	122-0345	1	Tube, Oil Drain
8	505-0057	1	Plug, Adapter Outlet (1/8")



OPTION 9 READI-PULL STARTER - KEY 1




REF.	PART NO.	QTY. USED		REF. NO.	PART NO.	QTY.	
	KIT, START	FR-COM	PI FTF	21	870-0110		†ΔNut. Speed Grip
	192-0325	1	Begin Spec E (Includes	22	526-0180		†ΔWasher, Flat (17/16" ID x
	192-0215	1	Parts Marked †)				7/8" OD x 1/8" Thk)
		ı	Specs A through D (Includes Parts Marked Δ)	23	526-0130	4	†∆Washer, Flat (17/64" ID x 1" OD x 1/16" Thk)
1	192-0045	1	†ΔRope and Grip Assembly	24	192-0309	1	†Wheel, Ratchet - Begin Spec E
			(Includes Parts Marked D)	25	516-0132		†ΔPin, Spiral - Brass
2	192-0043		-∆□Rope	26	526-0168	1	†ΔWasher, Flat (1-15/32" ID x
3	192-0044		·∆□Grip				3" OD x .047" Thk)
4	517-0025		-∆⊡Plug, Grip	27	815-0137	4	†∆Screw, Cap - Hex Head
5	526-0021	1 †	·∆□Washer, Flat (17/64" ID x				(1/4-20 x 1-1/4")
			3/4" OD x 1/16" T≿ki	28	850-0050	1	†∆Washer, Lock - Spring (3/8")
6	192-0153		†ΔWheel, Cog	29	800-0007	4	†ΔScrew, Cap - Hex Head
7	516-0138		†ΔPin, Roll				(1/4-20 x 1-1/4")
8	192-0039		†ΔSpring, Recoil	30	850-0040	8	†∆Washer, Lock - Spring (1/4")
9	526-0123		†∆Washer, Thrust	31	815-0137	2	†ΔScrew, Cap - Hex Head
10	192-0180	1	†∆Sheave, Rope (Includes Parts				(1/4-20 x 1-1/4")
			Marked *)	32	526-0158	4	†∆Washer, Flat (.261" ID x
11	192-0172		Δ*Pawl				1" OD x 1/8" Thk)
12	192-0165		Δ*Spring, Pawi	33	526-0015	2	†∆Washer, Flat (9/32" ID x
13	192-0168		Δ*Arm, Ratchet				9/16" OD x 1/16" Thk)
14	516-0110	4 1	r∆*Pin, Roll (2) Pawl (2) Ratchet Arm	34	192-0170	1	ΔWheel, Ratchet - Specs A through D
15	192-0167	1 †	Δ'Clamp, Rope	35	192-0218	2	ΔScrew, Cap - Hex Head -
16	192-0163	1	†∆Bearing, Sheave Hub				Specs A through D
17	192-0323		tΔScrew, Cap - Socket Head				
			(Special)	† -	Parts Include	ed in 192-	0325 Starter Kit.
18	862-0003	1	†∆Nut, Hex (3/8-16)	Δ-	Parts Include	ed in 192-	0215 Starter Kit.
19	192-0152		†∆Cover, Starter	-	Parts Include	ed in 192-	0045 Rope and Grip Assembly
20	192-0186			٠.	Parts Include	ed in 192-	0180 Rope Sheave.
40	125-0100	,	†∆Rina, Mountina				

192-0186


1 t∆Ring, Mounting

OPTION 10 GEAR REDUCTION (3.3:1)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	REDUCTION	N GEAR AS	SEMBLY	14	800-0007	4	Screw, Cap - Hex Head
	190-0444	1	Mounted Left Side				(1/4-20 x 1")
			Horizontal	15	515-0159	1	Key, Driven Gear
	190~0440	1	Mounted Right Side	16	518-0013	1	Ring, Retainer
			Horizontal	17	190-0202	1	Spacer, Bearing
2	190-0050	1	Housing - Includes Cover (Also	18	190-0192	1	Shaft, Take-Off
			Order 2 #516-0012 Pins)	19	515-0103	1	Key, Take-Off Shaft
3	516-0012	2	Pin, Dowel	20	510-0023	1	Cone, Roller Bearing
4	190-0020	1	Gasket, Housing to Engine	21	510-0024	1	Cup, Roller Bearing
5	190-0021	1	Gasket, Cover to Housing	22	850-0045	12	Washer, Lock - Spring (5/16")
6	190-0016	1	Plate, Bearing Retainer	23	505-0054	3	Plug, Pipe (1/4)
7	190-0115	1	Shim Set, End Play Adjustment	24	190-0306	2	Gasket, Bearing Plate to
8	509-0016	1	Seal, Oil				Housing
9	190-0195	1	Washer, Pinion Gear	25	800-0028	16	Screw, Cap - Hex Head
10	515-0142	1	Key, Pinion Gear				(5/16-18 x 1")
11	190-0447	1	Gear, Set (Pinion and Driven)	26	526-0063	4	Washer, Flat - Copper
12	510-0022	1	Cup, Roller Bearing				(17/64" ID x 7/16" OD x
13	510-0021	1	Cone, Roller Bearing				1/22" Thk)

OPTION 11 GEAR REDUCTION (4:1)



REF.	PART	QTY.	PART	REF.		QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1	REDUCTION	I GEAR AS		15	515-0159	1	Key, Driven Gear
	190-0193	1	Mounted Left Side Horizontal	16	518-0013	1	Ring, Retainer
			(No Longer Available)	17	190-0202	1	Spacer, Bearing
	190-0299	1	Mounted Hight Side Horizontal	18	190-0192	1	Shaft, Take-Off
			(No Longer Available)	19	515-0103	1	Key, Take-Off Shaft
	FOR REPL	ACEMENT		20	510-0023	1	Cone, Roller Bearing
	190-0440	1	Reduction Gear Assembly,	21	510-0024	1	Cup, Roller Bearing
			Mounted Right Side Horizontal	22	850-0045	12	Washer, Lock - Spring (5/16")
	190-0447	1	Gear, Set (Pinion & Driver)	23	PLUG, PIPE	(1/4)	
	190-0195	1	Washer, Pinion Gear		505-0054	3	Mounted Left Side and Mounted
	515-0142	1	Key, Pinion Gear				Right Side Gear Box
	190-0410	1	Mounted Vertical Down		505-0054	2	Mounted Vertical Down Gear
2	190-0050	1	Housing - Includes Cover (No				Box
			Longer Available) (Also Order	24	190-0306	2	Gasket, Bearing Plate to Housing
			2 #516-0012 Pins)	25	800-0028	12	Screw, Cap - Hex Head
3		2	Pin, Dowel				(5/16-18 x 1")
4		1	Gasket, Housing to Engine	26	526-0063	4	Washer, Flat - Copper
5		1	Gasket, Cover to Housing				(17/64"IDx7/16"ODx1/32"Thk)
6		1	Plate, Bearing Retainer	27	800-0007	4	Screw, Cap - Hex Head
7		1	Shim Set, End Play Adjustment				(1/4-20 x 1")
8			Seal, Oil	28	505-0007		Bushing, Reducer - Mounted
9		1	Washer, Pinion Gear				Vertical Down Gear Box
10		1	Key, Pinion Gear	29	518-0172	1	Vent, Mounted Vertical Down
11	190-0191	1	Gear, Pinion (No Longer				Gear Box
			Available)	30	509-0016	1	Seal, Oil
12		1	Cup, Roller Bearing				
13		1	Cone, Roller Bearing				
14	190-0190	1	Gear, Driven (No Longer Available)				

OPTION 12 CLUTCH (ROCKFORD)



 For components, check Clutch nameplate and contact your nearest Rockford Clutch Dealer.


(#10-32 x 1/2")

(1/8 NPT)

Elbow, Pipe - Street Brass, 90°

*Hardware Mounting Package.

927-0404 (APRIL 1981)



502-0020

302-0270

- Parts Included in 302-1361 Ammeter.

(10-32)

Line, Oil

Elbow, Pipe

2

2

1

10

12

13

800-0002

850-0040

501-0004


502-0055


Screw, Cap - Hex Head

Washer, Lock - Spring (1/4")

(1/4-20 x 3/8")

OPTION 14 AIR HOUSING - VACU-FLO COOLING (AND FLYWHEEL)





REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
1	SCROLL, AIF	DISCHA	ARGE (Includes Parts Marked †)
	134-3103	1	Mounted in 6 o'clock position
	134-3070	1	Mounted in 9 o'clock position
	134-3041	1	Mounted in 3 o'clock or
			12 o'clock position •
2	HOUSING, B	LOWER	•
	134-2828	1	Begin Spec J
	134-2138	1	Spec G and H
3	192-0272	1	Sheave, Rope
4	134-0565	1	Wheel, Blower
5	FLYWHEEL		
	104-0302	1	Standard
	104-0491	1	Engine with Optional Spark Advance
6	517-0021	2	Plug, Dot Button
7	800-0002	4	Screw, Cap - Hex Head (1/4-20 x 3/8")
8	853-0013	4	Washer, Lock - ET (1/4")
9	526-0015	4	Washer, Flat (9/32" ID x 9/16"OD x 1/16" Thk)


1.	Sec.			
REF.	PART	QTY.	PART	
NO.	NO.	USED	DESCRIPTION	
10	800-0010	4	Screw, Cap - Hex Head (1/4-20 x 1-3/4")	
11	850-0040	4	Washer, Lock - Spring (1/4")	
12	104-0170	1	Screw, Cap - Hex Head (Special) - Flywheel Mounting	
13	134-2956	1	†Guard, Scroll Outlet	
14	815-0421	4	tScrew, Machine - Hex Head (#10-16 x 1/2")	
15	405-1059	1	Anti-Vibration Package	
16	812-0099	1	Screw, Round Head - Machine - Coil Mounting - Begin Spec J (10-24 x 7/16")	
17	870-0177	1	Nut, Speed - Coil Mounting - Begin Spec J (#10)	


Vacu-flo units with oil filter also see Oil Filter Group - Option 8.
 Parts included in Air Discharge Scroll Assembly.

927-0404 (APRIL 1981)

CS-1073

OPTION 15 FUEL SYSTEM (GASEOUS FUEL)






REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	148-0390	1	Repair Kit, Gas Regulator	8	505-0099	1	Nipple (1/4 x 7/8") -
1	148-0311	1	Regulator, Gas (Garretson				Regulator Outlet
			Manufacturer).	9	505-0038	1	Elbow (1/4") - Regulator
3	*CARBURET	OR, GAS-	GASOLINE (Includes Mounting				Outlet
	Gasket) (Ir	ncludes Pa	arts Marked †)	10	505-0017	1	Bushing (3/8 x 1/4") Regulator
	143-0338	1	Spec G Only (Manual Choke)				Outlet
	141-0887	1	Begin Spec H (Manual Choke)	11	148-0107	1	Vent, Regulator
	143-0339	1	Spec G Only (Electric Choke)	12	504-0007	1	Valve, Shut-Off - Fuel Pump
	141-0888	1	Begin Spec H (Electric Choke)				inlet
3	*CARBURET	OR, GAS (Includes Mounting Gasket)	13	141-0281	1	†Gasket, Carburetor Mounting
	(Includes I	Parts Mark	red †)	14	149-0136	1	Plate, Fuel Pump Hole
	141-0840	1	Spec G Only				Crankcase (Gas Fuel Sets)
	141-0892	1	Begin Spec H	15	143-0231	1	Wire, Choke Stop (Gas-
4	503-0315	1	Hose, Regulator to Carburetor				Gasoline Units)
			(1/2" ID x 2 FT)	16	526-0063	2	·
5	503-0032	2	Clamp, Hose		020-0000	2	Washer, Flat, Copper (17/64" ID x 7/16 OD x
6	505-0302	1	Nipple (1/4 x 1-1/2"), Half				1/32" Thk)
7	505-0057	1	Plug (1/8") - Regulator	17	806-0009	2	Screw, Cap - Counterbore (1/4-20 x 1.1")

^{* -} See Separate Group for Components and Gasket Kit. † - Parts Included in 141-0840/141-0887/141-0888/141-0892 Carburetor Kit.


OPTION 16 RESERVOIR (DAY) TANK (ONE QUART)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	2
	159-0591	1	Kit, Tank (Includes all parts in this group)	° ,
1	159-0041	1	Cap, Vent	<u> </u>
2	415-0055	1	Bracket, Vent Cap	<u>.</u>
3	505-0028	1	Coupling, Pipe	₩—5
4	505-0016	1	Bushing, Reducer (3/8 to 1/8")	ñ
5	502-0116	1	Connector, Compression	, g / ll
6	159-0345	1	Tubing, Copper (5/16 x 12")	
7	502-0024	1	Elbow, Compression (90°)	16 60-7
8	159-0294	1	Tank, Reservoir	
9	159-0556	1	Band, Reservoir Tank	18 00
10	159-0612	1	Bracket, Reservoir Tank Mounting	10
11	502-0020	1	Elbow, Street (90°)	
12	501-0005	1	Line, Fuel - to Fuel Pump (18")	(U)8
13	504-0086	1	Valve, Shut-off	
14	501-0007	1	Line, Fuel - to Carburetor (24")	
15	505-0057	1	Plug, Tank Drain	
16	812-0156	1	Screw, Machine - Round Head (1/4-20 x 1-1/2")	13 12
17	850-0040	1	Washer, Lock - Spring (1/4")	
18	862-0001	1	Nut, Hex (1/4-20)	9—15 F5-1197

OPTION 17 RESERVOIR (DAY) TANK (TWO QUART)




OPTION 18 FUEL TANK (SIDE MOUNTED)



REF. NO.	PART NO.	QTY. USED		REF. NO.	PART NO.	QT" USE	
	159-0984	1	Kit, Fuel Tank with Gauge	7	504-0013	1 "	†*Valvo, Shut-off
			(Includes Parts Marked *)	8	505-0057	1	†*Plug, Tank Drain
	159-0597	1	Kit, Fuel Tank Without	9	502-0020	1	†*Elbow, Carburetor Inlet
			Gauge (Includes Parts	10	813-0108	2	†*Screw, Machine - Round Head
			Marked †)				(#10-32 x 1-1/2")
1	159-0981	1	†*Tank, Fuel (Less Cap)	11	870-0053	2	†*Nut, Hex (#10-32)
2	159-0596	2	†*Strap, Fuel Tank	12	159-0020	1	†Cap, Fuel Tank (For 2-5/16"
3	159-0595	2	†*Bracket, Fuel Tank				Filler Neck) - Late Models
4	134-0599	1	†*Clip, Fuel Line	13	159-0007	1	Cap, Fuel Tank (For 1-3/4"
5	501-0008	1	†*Line, Fuel				Filler Neck) - Early Models
6	193-0207	1	*Cap and Gauge, Fuel Tank (For 2-5/16" Filler Neck) - Late Models				9-0597 Fuel Tank Kit. 1-0984 Fuel Tank Kit


OPTION 19 BREAKER BOX (HIGH PROFILE)






REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	160-1135	1	Box Assembly, (Includes Parts Marked *)
1	160-0931	1	*Guide, Plunger
2	160-0002	1	*Point Set
3	160-0349	1	*Terminal and Block Assembly
4	160-0075	1	*Cam, Point Adjusting
5	160-0428	1	*Strap, Point Set to Terminal
6	160-0150	1	*Gasket, Cover
7	160-0930	1	*Cover, Breaker Box
8	850-0025	2	*Washer, Lock - Spring (#8)
9	812-0077	2	*Screw, Machine - Round Head (#8-32 x 3/8")
10	312-0069	1	*Condenser (.3 Mfd)
11	802-0035	2	*Screw, Socket Head (1/4-20 x 7/8")
12	850-0040	2	*Washer, Lock - Spring (1/4")
13	526-0214	2	Washer, Flat (17/64 ID x 1/2 OD x 1/16 Thk)
14	BUSHING,	GUIDE	
	160-1041	1	*Begin Spec J
	160-0929	1	Spec A through H
15	160-1040	1	*Gasket, Mounting - Begin Spec J
16	160-0043	1	Gasket, Spec A through H
17	160-0723	1	*Plunger, Breaker
18	160-0261	1	*Wick
19	815-0285	3	*Screw, Machine - Round Head W/ET Washer (#8-32 x 5/16")

* - Parts Included in 160-1135 Breaker Box Assembly.




OPTION 20 THERMO MAGNETIC CHOKE



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	153-0429	1	Replacement Kit (Includes	18	518-0129	1	Ring, Retainer
			Complete Choke - less leads)	. 19	332-0876	1	Terminal Ground
5	153-0385	1	Plate, Mounting	20	LEAD, CHO	KE	
6	153-0386	1	Body		336-1550	1	Choke to Ground
7	153-0389	1	Cover		336-1549	1	Choke Solenoid Ground
8	153-0391	1	Core, Solenoid	21	815-0161	2	Screw (10-32 x 3/8")
9	153-0395	1	Armature	22	526-0008	1	Washer, Flat
10	307-1203	1	Coil, Solenoid Assembly	23	850-0030	1	Washer (#10), Lock
-11	153-0392		Frame, Solenoid	24	813-0107		Screw (10-32 x 1-1/4")
12	153-0387	1	Spring	25	854-0007	2	Washer (#8), Lock
13	153-0390	1	Lever, Thermostat	26	812-0076	2	Screw (8-32 x 5/16")
14	526-0018	1	Washer	27	862-0015	1	Nut, Hex (5/16-18)
15	870-0134	1	Painut (1/4-20)	28	854-0017	1	Washer, (5/16), Lock
16	153-0399	2	Insulator	29	526-0022	1	Washer, Flat
17	153-0400	1	Heater Assembly				•


OPTION 21 STARTER (SOLENOID SHIFT) KEY 2




							_
REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART
1	191-0790	1	Motor, Starter (includes Parts	16	191-0749	1	*Lever Assembly
			Marked *)	17	191-0750	1	*Spring, Lever
2	191-0508	1	Flange, Starter Motor	18	191-0751	1	*Spring, Lever
3	850-0050	2	Washer, Lock - Spring (3/8")	19	191-0752	1	*Holder, Spring
4	800-0049	1	Screw, Cap - Hex Head	21	191-0754	1	*Washer, Plain
			(3/8-16 x 7/8")	22	191-0755	. 1	*Washer, Plain
5	800-0050	1	Screw, Cap - Hex Head	23	191-0756	1	*Washer, Insulation
			3/8-16 x 1")	24	191-0757	4	*∆Brush
6	850-0050	2	Washer, Lock - Spring (3/8")	25	191-0758	4	*Spring, Brush
7	102-0455	2	Screw, Cap - Hex Head (Special)	26	191-0759	2	*Bolt, Through
8	134-2131	1	Baffle, Air	27	191-0760	3	*Screw, Machine
9	191-0806	1	*Yoke Assembly (Frame) -	28	191-0761	1	*Switch Assembly, Solenoid
			(Includes Parts Marked △)	29	191-0762	1	*∆Coil Assembly, Field
10	191-0743	1	*Armature	30	191-0763	•	*Bearing, Front
11	191-0744	1	*Clutch	31	191-0764	•	*Bearing, Rear
12	191-0745	1	*Stop, Pinion	32	191-0765	4	*ΔPole Shoe
13	191-0746	1	*Ring	33	191-0766	4	*AScrew
14	191-0747	i	*Washer, Plain	55	131-0100	7	70016#

 $^{^{\}star}$ - Parts Included in 191-0790 Starter Motor. Δ - Parts Included in 191-0806 Yoke Assembly.

OPTION 22 GOVERNOR CONTROL (VARIABLE SPEED).





REF.	PART NO.	QTY. USED	PART DESCRIPTION
	152-0085	1	Bracket and Control Arm Assembly Variable Speed - Complete (Includes Parts Marked *)
1	800-0005	1	*Screw, Cap - Hex Head (1/4-20 x 3/4")
2	526-0015	2	*Washer, Flat (9/32" ID x 9/16" OD x 1/16" Thk)
3	152-0083	1	*Lever, Control
4	815-0199	2	*Screw, Machine - Fillister Head (#10-32 c 5/16")
5	152-0086	1	*Bracket, Mounting
. 6	870-0131	2	*Nut, Hex with ET Lock Washer (#10-32)
8	152-0041	1	*Washer, Tension
9	870-0065	1	*Nut, Hex - Self Locking (1/4-20)
10	152-0090	1	Stud, Speed Adjusting
11	150-0621	1	Nut, Special - Speed Adjusting Stud
12	821-0008	2	Screw, Cap - Hex Head Locking (1/4-20 x 5/16")
13	150-1000	1	Extension, Governor Arm
14	815-0181	1	Screw, Cap - Hex Head with ET Lock Washer (#10-32 x 1/2")

* - Parts Included in 152-0085 Bracket and Arm Assembly.

OPTION 23 FUEL FILTER

REF.	PART	QTY.	PART		
NO.	NO.	USED	DESCRIPTION	- A	A888A
1	149-0079	1	Bowl Assembly, Sediment - Complete (Includes Parts Marked *)		
2	149-0150	1	*Bowl Only		` 3
3	149-0149	1	*Gasket, Bowl Mounting		
4	149-0202	1	*Screen		
· D.	الحاملين المساملة	- 110 007			F5-1204

' - Parts Included In 149-0079 Sediment Bowl Assembly.

OPTION 24 CARBURETOR PARTS (GASOLINE, ELECTRIC CHOKE) SPEC G ONLY)

REF NO.		QTY. USED		· f	4
	141-0792	1	Carburetor, Gasoline - Electric Choke (Includes Mounting Gasket)	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)		
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)	4	
	141-0281	1	*Gasket, Carburetor Flange	30 🖁 19 18	
1	143-0202	1	Valve, Throttle	i a i	
3	143-0204	1	Valve, Choke - Electric Choke	16	
4	143-0330	1	**Needle, Idle Jet and High Speed Adjusting		
5	143-0329	1	**Nozzle		
6	143-0315	1	Shaft, Choke - Electric Choke	6 3	
7	143-0208	1	Screw and Gasket, Bowl	13 -12	
8	143-0015	1	*Gasket, Fuel Inlet Valve		
9	143-0209	1	*Gasket, Bowl Screw	8 1 2	
10	143-0105	1	Float and Lever		
11	143-0210	1	Bowl		
12	143-0077	1	*Gasket, Bowl Ring	14<5	
13	141-0703	1	**Pin, Float Lever		
14	143-0341	1	**Valve, Fuel Inlet		
15	143-0213	1	Screw, Idle Adjusting	7-10	
16	812-0014	4	**Screw (#3-48 x 3/16) - Choke		
			and Throttle Valve		
17	143-0110	1	Plug Expansion	11	
18	143-0214	1	Spring, Throttle Adjusting Screw	1 1 1	
19	143-0112	1	Spring, Idle Adjusting Screw		
29	143-0342	1	Diaphragm - Electric Choke	0 -9-7	
30	854-0003	4	**Washer, Lock (It #3)		


^{* -} Parts Included in 143-0201 Carburetor Gasket Kit.





^{** -} Parts Included in 143-0332 Carburetor Repair Kit.

OPTION 25 CARBURETOR PARTS (GAS-GASOLINE, MANUAL CHOKE) SPEC G ONLY

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	143-0338	1	Carburetor, Gas-Gasoline
			Manual Choke (Includes
	440 0000		Mounting Gasket)
	143-0332	1	Kit, Carburetor Repair
	140 0001		(Includes Parts Marked **)
•	143-0201	1	**Kit, Carburetor Gasket
	141-0281	1	(Includes Parts Marked *)
1	143-0202	1	'Gasket, Carburetor Flange Valve, Throttle
3	143-0202	1	Valve, Throttle Valve, Choke - Manual Choke
4	143-0330		
7	145-0000	•	**Needle, Idle Jet and High Speed Adjusting
5	143-0329	1	**Nozzle
6	143-0221	i	Shaft and Lever, Choke -
_		•	Manual Choke
7	143-0208	1	Screw and Gasket, Bowl
8	143-0015	1	*Gasket, Fuel Inlet Valve
9	143-0209	1	*Gasket, Bowl Screw
10	143-0105	1	Float and Lever
11	143-0210	1	Bowl
12	143-0077	1	*Gasket, Bowl Ring
13	141-0703	1	**Pin, Float Lever
14	143-0341	1	**Valve, Fuel Inlet
15	143-0213	2	Screw, Idle Adjusting
16	812-0014	4	**Screw (#3-48 x 3/16") - choke
			and Throttle Valve
17	143-0110	1	Plug, Expansion
18	143-0214	1	Spring, Throttle Adjusting
			Screw
19	143-0112	2	Spring, Idle Adjusting Screw
24	145-0308	1	Tube, Gas Inlet - Gas-Gasoline
			Only
27	854-0003	4	"Washer, Lock (It #3)







OPTION 26 CARBURETOR PARTS (GAS-GASOLINE, ELECTRIC CHOKE) SPEC G ONLY

REF. NO.	PART NO.	QTY. USED		िम
	143-0339	1	Carburetor, Gas-Gasoline Electric Choke (Includes Mounting Gasket)	
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)	4
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)	4 17 15
	141-0281	1	*Gasket, Carburetor Flange	30 9 19 18-19
1	143-0202	1	Valve, Throttle	16
3	143-0204	1	Valve, Choke - Electric Choke	
4	143-0330	1	"Needle, Idle Jet and High Speed Adjusting	
5	143-0329	1	**Nozzle	
6	143-0315	1	Shaft, Choke - Electric Choke	6 3
7	143-0208	1	Screw and Gasket, Bowl	13' -12
8	143-0015	1	*Gasket, Fuel Inlet Valve	
9	143-0209	1	*Gasket, Bowl Screw	8 40 🗓
10	143-0105	1	Float and Lever	! A N
11	143-0210	1	Bowl	14
12	143-0077	1	*Gasket, Bowl Ring	
13	141-0703	1	**Pin, Float Lever	100-
14	143-0341	1	**Valve, Fuel Inlet	10
15	143-0213	2	Screw, Idle Adjusting	
16	812-0014	4	**Screw (#3-48 x 3/16") - choke and Throttle Valve	
17	143-0110	1	Plug, Expansion	→11
18	143-0214	1	Spring, Throttle Adjusting Screw	
19	143-0112	2	Spring, Idle Adjusting Screw	○ -9-7
24	145-0308	1	Tube, Gas Inlet	
29	143-0342	1	Diaphragm - Electric Choke	_
30	854-0003	4	*Washer, Lock (It #3)	


^{* -} Parts Included in 143-0201 Carburetor Gasket Kit.
** - Parts Included in 143-0332 Carburetor Repair Kit.







OPTION 27 CARBURETOR PARTS (GAS) SPEC G ONLY

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	141-0840	1	Carburetor, Gas (Includes Mounting Gasket)
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)
	141-0281	1	*Gasket, Carburetor Flange
1	143-0202	1	Valve, Throttle
7	143-0208	1	Screw and Gasket, Bowl
9	143-0209	1	*Gasket, Bowl Screw
11	143-0210	1	Bowl
12	143-0077	1	*Gasket, Bowl Ring
15	143-0213	1	Screw, Idle Adjusting
16	812-0014	4	**Screw (#3-48 x 3/16") - Choke and Throttle Valve
17	143-0110	1	Plug, Expansion
18	143-0214	1	Spring, Throttle Adjusting Screw
19	143-0112	1	Spring, Idle Adjusting Screw
24	145-0308	1	Tube, Gas Inlet
28	505-0008	1	Plug (1/8")









FS-1191


OPTION 28 CARBURETOR PARTS (GASOLINE, ELECTRIC CHOKE) BEGIN SPEC H

REF. NO.		QTY. USE		14-1 8.0	
	141-0879	1	Carburetor, Gasoline - Electric Choke (Includes Mounting Gasket)	18 15-8 8-13 3	
	141-0797	1	Kit, Carburetor Repair (Includes Parts Marked*)	4	
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)		
	141-0281	1	£*Gasket, Carburetor Flange	6 5	٥,
1	141-0708	1	Bowl, Fuel		P
2	141-0741	1	Plate, Choke		
3	141-0698	4	Screw & Washer, Choke and Throttle Plate Mounting	3 9 8	
4	141-0706	1	Plate, Throttle	2	
5	141-0705	1	*Retainer, Seat		
6	141-0661	1	£*Seal, Rubber	(Ca.)-11	
7	141-0830	1	*Valve Seat Assembly, Fuel		
8	141-0811	1	£Washer, Fuel Valve Seat	29	
9	141-0703	1	*Shaft, Float	10	
10	141-0702	1	Float Assembly		
11	141-0701	1	£'Gasket, Bowl to Body		
12	141-0700	1	Screw, Throttle Stop		
13	141-0711	1	Spring, Throttle Stop		
14	141-0713	1	Needle, Idle Adjusting		
15	141-0710	1	Spring, Idle Needle	50 400	
16	141-0077	1	£*Washer, Main Jet Assembly	©-16 FS-1207	
17	141-0712	1	Jet Assembly, Main (Adjustable)	No.	
18	141-0679	1	Shaft, Choke	₽-17	
22	141-0709	1	Shaft and Lever Throttle	T T	
29	141-0799	1	Spring, Float	~	


^{* -} Parts Included in 141-0797 Carburetor Repair Kit. £ - Parts Included in 141-0748 Carburetor Gasket Kit.

OPTION 29 CARBURETOR PARTS (GAS-GASOLINE, MANUAL CHOKE) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	1	4-11-12
	141-0887	1	Carburetor, Gas-Gasoline Manual Choke (Includes Mounting Gasket)	19 20	5-13
	141-0747	1	Kit, Carburetor Repair (Includes Parts Marked *)	000	
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)	21	6 5
	141-0281	1 :	£*Gasket, Carburetor Flange	10)	1
1	141-0708	1	Bowl, Fuel	98-97	2
2	141-0741	1	Plate, Choke	3-0-1	
3	141-0698	4	Screw & Washer, Choke and Throttle Plate Mounting	2 7	_
4	141-0706	1	Plate, Throttle	لم لكم	> _11
5	141-0705	1	*Retainer, Seal	ر د	۰۰ استر و ده
6	141-0661	1	£*Seal, Rubber	29	_
7	141-0830	1	*Valve Seat Assembly, Fuel	23	£) }_10
8	141-0811	1	£Washer, Fuel Valve Seat		- 18
9	141-0703	1	*Shaft, Float		2
10	141-0702	1 `	Float Assembly		
11	141-0701	1	£*Gasket, Bowl to Body		"
12	141-0700	1	Screw, Throttle Stop	was a second of the second of	
13	141-0711	1	Spring, Throttle Stop		
14	NEEDLE, I	DLE ADJUS	STING		D-16
	141-0713	2	Gas-Gasoline Units	9	3
15	SPRING, IE	LE NEEDL	.E	<u></u>	≦ }—17
	141-0710	2	Gas-Gasoline Units	k	₽
16	141-0077	1	£*Washer, Main Jet Assembly	-	(Jr
17	141-0712	1	Jet Assembly, Main (Adjustable)		
18	SHAFT, CH	IOKE			
	141-0742	1	Manual Choke Units		
19	141-0699	1	Washer		
20	141-0697	1 :	£*Seal, Felt		24
21	141-0203	1	*Retainer, Felt Seal		,23
22	141-0709	1	Shaft and Lever, Throttle		
23	141-0733	1	Spring, Main Gas Needle		Maril
24	141-0734	1	Needle, Main Gas Adjusting		14 - 1
29	141-0799	1	*Spring, Float		o) 同




 $^{^\}star$ - Parts included in 141-0747 Carburetor Repair Kit. £ - Parts included in 141-0748 Carburetor Gasket Kit.




FS-1206

OPTION 30 CARBURETOR PARTS (GAS-GASOLINE, ELECTRIC CHOKE) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	14-4 €	
	141-0888	1	Carburetor, Gas-Gasoline Electric Choke (Includes Mounting Gasket)	18 15-8 8-13	Y
	141-0747	1	Kit, Carburetor Repair (Includes Parts Marked *)		(م
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)		,
	141-0281	1	£*Gasket, Carburetor Flange	6 5	
1	141-0708	1	Bowl, Fuel		
. 2	141-0741	1	Plate, Choke		
3	141-0698	4	Screw & Washer, Choke and Throttle Plate Mounting	3 7 7	
4	141-0706	1	Plate, Throttle		
5	141-0705	1	*Retainer, Seal		
6	141-0661	1	£*Seal, Rubber	ا ا – (ر دلیکه) – ۱۱	
7	141-0830	1	*Valve Seat Assembly, Fuel		
8	141-0811	1	£Washer, Fuel Valve Seat	29	
9	141-0703	1	*Shaft, Float	10	
10	141-0702	1	Float Assembly		
11	141-0701	1	£*Gasket, Bowl to Body		
12	141-0700	1	Screw, Throttle Stop	(· §)	
13	141-0711	1	Spring, Throttle Stop	1-1	
14	NEEDLE, IDLE ADJUSTING				
	141-0713	2	Gas-Gasoline Units		
15	SPRING, IDL	E NEEDI	LE	© -16	
	141-0710	2	Gas-Gasoline Units	Ä	
16	141-0077	1	£*Washer, Main Jet Assembly	₩-17	
17	141-0712	1	Jet Assembly, Main (Adjustable)	Ţ.	
18	SHAFT, CHO	KE			
	141-0679	1	Electric Choke		
22	141-0709	1	Shaft and Lever, Throttle		
23	141-0733	1	Spring, Main Gas Needle Gas-Gasoline Units		
24	141-0734	1	Needle, Main Gas Adjusting - Gas-Gasoline Units	24 23	
29	141-0799	1	*Spring, Float		
	Davida La alcoda		0747 O - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -		




^{£ -} Parts Included in 141-0748 Carburetor Gasket Kit.





FS-1205

OPTION 31 CARBURETOR PARTS (GAS) BEGIN SPEC H


REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
	141-0892	1	Carburetor, Gas (Includes Mounting Gasket)
	141-0747	1	Kit, Carburetor Repair (Includes Parts Marked *)
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)
	141-0281	1	£*Gasket, Carburetor Flange
1	141-0708	1	Bowl. Fuel
3	141-0698	2	Screw & Washer, Choke and Throttle Plate Mounting
4	141-0706	1	Plate, Throttle
5	141-0705	1	*Retainer, Seal
6	141-0661	-	£*Seal, Rubber
11	141-0701		£*Gasket, Bowl to Body
12	141-0700	1	Screw, Throttle Stop
13	141-0711	1	Spring, Throttle Stop
14	NEEDLE, ID	LE ADJU:	
		1	Gas Only Units
			(Not Available)
15	SPRING, ID	LE NEEDI	
	141-0710	1	Gas Only Units
16	141-0077	1 .	£*Washer, Main Jet Assembly
22	141-0709	1	Shaft and Lever, Throttle
23	141-0733	1	Spring, Main Gas Needle
24	141-0734	1	Needle, Main Gas Adjusting
25	141-0736	1	Nut, Bowl
29	141-0799	1	*Spring, Float
30	505-0008	1	Plug, Pipe (1/8")
٠.	Parts Include	ed in 141-	0747 Carburator Rapair Kit








MISCELLANEOUS OPTIONAL PARTS





927-0404 (APRIL 1981)

MISCELLANEOUS OPTIONAL PARTS

REF. NO.	PART NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USED	PART Description
1	102-0558	1	Heater, Oil Base	15	193-0108	1	Sender, Oil Pressure
	ARM, GOVE	RNOR PU	LL - CONSTANT SPEED	16	502-0053	1	Elbow, Street (45°)
	GOVERNOR	}		17	153-0327	1	Bracket, Choke
2	150-0635	1	Rear Pull	18	518-0176	1	Clip, Choke Bracket
3	150-0755	1	Front Pull	19	134-1889	1	Guard, Flywheel - Rotating
4	150-0790	1	Left Pull	20	309-0237	1	Pressure Switch - Low Oil
5	150-0752	1	Right Pull				(8-10 PSI)
6	154-0973	2	Gasket, Exhaust Manifold	21	153-0464	1	Bracket, Choke Cable
7	154-0998	1	Manifold, Exhaust	22	153-0351	1	Cable, Choke Short
8	155-0906	1	Muffler, Exhaust	23	155-1660	2	Muffler (Ray Gun)
9	140-0645	1	Adapter, Air Cleaner	24	155-1239	2	Clamp, Muffler (1-5/8")
10	140-0500	1	Cleaner, Air	25	154-1757	2	Adapter Assembly, Manifold
11	140-0519	1	Band, Air Cleaner				
12	503-0365	2	Clamp, Air Cleaner Hose				
13	503-0444	1	Hose, Air Cleaner (2" ID 10 x 30" lg)				
14	505-0618	1	Cap, Pipe (1-1/2")				